

## TL-ULTRALIGHT STINGSPORT

# How To Provide Eye Protection For The VOR/ILS Antennae

---

If you are installing a Garmin SL30, the VOR/ILS antenna location that the factory recommends may present some safety issues during ground operations. The ends of the antenna are exactly at eye level and are very hard to see from the rear.

To help prevent an accident during maintenance, we have installed solid rubber balls on the antenna tips. Simply drill a small hole half way into the rubber ball and push it on the antenna after your flight. The balls will come off in flight if you forget to remove them during preflight. A ribbon connecting the two rubber balls might help you to see them during the preflight..



**VOR/ILS ANTENNAE ARE ROUGHLY AT EYE LEVEL  
(BOTH SIDES OF RUDDER)**



**HOLE DRILLED HALFWAY THROUGH RUBBER BALL**



**BALL PLACED OVER ANTENNA TIP (BOTH SIDES)**