


TL-ULTRALIGHT STINGSPORT

How To Adjust The Brake Pedals

The angle of the brake pedals with respect to the rudder pedals can be adjusted fore and aft. If you find it difficult to avoid riding the brakes, angle the brake pedals forward, away from your toes. On the other hand, if you find it a stretch to reach the brakes, angle the brake pedals aft, toward your toes.




BRAKE AND RUDDER PEDALS AS INSTALLED

The adjustment is made by lengthening or shortening the push-tubes that connect the brake pedals to the master cylinders, as shown in the following photos.



¾ VIEW



SIDE VIEW

To adjust the brake pedal angle:

1. Loosen the stop nut.
2. Turn the internally threaded pushtube to lengthen or shorten.
3. Re-tighten the stop nut to lock the pushtube adjustment in place.